

1996-1998 HONDA CIVIC TR STYLE FRONT BUMPER LIP INSTALLATION INSTRUCTIONS

If you experience any difficulties that the instruction did not cover, Please seek assistance at a local automotive shop

Please wear protection before you work on any vehicle.

/

An assistant is useful when removing the front bumper from your vehicle.

Please be cautions when working with the bumper or any parts belonging to the vehicles's body to prevent scratching.

Do not make direct contact with the halogen bulbs or the wire assembly until the unit has cooled down after use.

TOOLS AND SUPPLIES REQUIRED

Electric Drill w/Phillips Head Bit

Product Part Numbers:

LPF-CV964T-ABS





1996-1998 HONDA CIVIC TR STYLE FRONT BUMPER LIP INSTALLATION INSTRUCTIONS

WWW.SPECDTUNING.COM

If you experience any difficulties that the instruction did not cover, Please seek local auto shop for advise. Please wear protection before you work on your vehicle.

An assistant is helpful when removing the front bumper.

Please be careful while working with the bumper or body part to avoid scratching.

Do not make direct contact with the halogen bulb or the wire assembly until the unit has cooled down after use.



1. Fasten the chin spoiler to the front bumper with (2) self tapping screws



2. Tug firmy and position the chin spoiler on the other side of the front bumper



3. Fasten the chin spoiler with the (2) self tapping screws



4. The installation is now complete