

# SPEC-D *Tuning*

## 2011 MAZDA 2 LED TAIL LIGHTS INSTALLATION INSTRUCTIONS

If you experience any difficulties that the instruction did not cover, Please seek assistance at a local automotive shop

Please wear protection before you work on any vehicle.



An assistant is useful when removing the front bumper from your vehicle.

Please be cautious when working with the bumper or any parts belonging to the vehicle's body to prevent scratching.

Do not make direct contact with the halogen bulbs or the wire assembly until the unit has cooled down after use.

### TOOLS AND SUPPLIES REQUIRED

Phillips Screwdriver

Handy Remover

### Product Part Numbers:

LT-MZD211GLED-TM

LT-MZD211CLED-TM

LT-MZD211JMLED-TM



## 2011 MAZDA 2 LED TAIL LIGHTS INSTALLATION INSTRUCTIONS

If you experience any difficulties that the instruction did not cover, Please seek assistance at a local automotive shop

Please wear protection before you work on any vehicle.



An assistant is useful when removing the front bumper from your vehicle.

Please be cautions when working with the bumper or any parts belonging to the vehicles's body to prevent scratching.

Do not make direct contact with the halogen bulbs or the wire assembly until the unit has cooled down after use.



1. (2) Phillips head screws location



2. Remove the (2) phillips head screws



3. Remove the tail light



4. Unplug the tail light sockets



5. Remove the brake light bulb from the socket

please see the " L.E.D. tail lights installation instructions"  
If your tail lights don't have L.E.D. you can skip the installation instructions.



6. Plug in the LED tail light into the harness



7. Place the light sockets in the LED tail light



8. Place the LED tail light in stock location and tighten the (2) phillips head screws



9. Please repeat the steps in order from 1 to 8 for  
the opposite side  
The installation is now complete